



Owner's Manual



(LED Monitor*)

* LG LED Monitor applies LCD screen with LED backlights.

Please read this manual carefully before operating your set and retain it for future reference.

45GR75DC

45GR65DC

www.lg.com

Copyright © 2023 LG Electronics Inc. All Rights Reserved.

TABLE OF CONTENTS

LICENSE.....3

OPEN SOURCE SOFTWARE NOTICE INFORMATION4

ASSEMBLING AND PREPARING 4

- Supported Drivers and Software5
- Product and Button Description.....5
 - How to Use the Joystick Button
- Moving and Lifting the Monitor.....6
 - Installing on a Table
 - Adjusting the Stand Height
 - Adjusting the Angle
 - Using the Kensington Lock
 - Installing the Wall Mount Plate
 - Installing on the Wall

USING THE MONITOR..... 13

- Connecting to a PC..... 13
 - HDMI Connection
 - DisplayPort Connection
 - USB-C connection
- Connecting AV Devices..... 14
 - HDMI Connection
- Connecting Peripherals..... 15
 - USB Device connection
 - Connecting Headphones

USER SETTINGS 16

- Activating the Main Menu 16
 - Main Menu Features
- User Settings 18
 - Menu Settings

TROUBLESHOOTING..... 30

PRODUCT SPECIFICATION 33

- Factory Support Mode..... 35
- HDMI Timing (Video)..... 37
- Power LED 37
- Beep Guide..... 38

LICENSE

Each model has different licenses. Visit www.lg.com for more information on the license.



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



The SuperSpeed USB Trident logo is a registered trademark of USB Implementers Forum, Inc.



VESA, VESA logo, DisplayPort compliance logo and DisplayPort compliance logo for dual-mode source devices are all registered trademarks of the Video Electronics Standards Association.



For DTS patents, see <http://patents.dts.com>.

Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together, Headphone:X, and the DTS Headphone:X logo are registered trademarks and/or trademarks of DTS, Inc. in the United States and/or other countries. © DTS, Inc. All Rights Reserved.

OPEN SOURCE SOFTWARE NOTICE INFORMATION

To obtain the source code that is contained in this product, under GPL, LGPL, MPL, and other open source licenses that have the obligation to disclose source code, and to access all referred license terms, copyright notices and other relevant documents, please visit <https://opensource.lge.com>.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid to anyone in receipt of this information for a period of three years after our last shipment of this product.

ASSEMBLING AND PREPARING

CAUTION

- Always use genuine LG components to ensure safety and product performance.
- The product warranty will not cover damage or injury caused by the use of unauthorized components.
- It is recommended that use the supplied components.
- If you use generic cables not certified by LG, the screen may not display or there may be image noises.
- Illustrations in this document represent typical procedures, so they may look different from the actual product.
- Do not apply foreign substances (oils, lubricants, etc.) to the screw parts when assembling the product. (Doing so may damage the product.)

- Applying excessive force when tightening screws may cause damage to the monitor. Damage caused in this way will not be covered by the product warranty.
- Do not carry the monitor upside down by just holding the base. This may cause the monitor to fall off the stand and could result in personal injury.
- When lifting or moving the monitor, do not touch the monitor screen. The force applied to the monitor screen may cause damage to it.
- For wave pattern on appearance, unlike the general method of coating, it's applied to added glittering material in raw material. With no peeled-off appearance, it has good durability. Please use it with confidence because there is no problem in using the product at all.

NOTE


- The components may look different from those illustrated here.
- Without prior notice, all product information and specifications contained in this manual are subject to change to improve the performance of the product.
- To purchase optional accessories, visit an electronics store or an online shopping site, or contact the retailer from where you purchased the product.
- The power cord provided may differ depending upon the region.

Supported Drivers and Software

You can download and install the latest version from the LGE website (www.lg.com).

| Drivers and Software | Installation Priority |
|----------------------|-----------------------|
| Monitor Driver | Recommended |
| OnScreen Control | Recommended |
| Dual Controller | Optional |

Product and Button Description










Joystick Button

How to Use the Joystick Button

You can easily control the functions of the monitor by pressing the joystick button or moving it left/right/up/down with your finger.


Basic Functions

| | | | |
|---|---|-----------------------------------|---|
|  |  | Power on | Press the joystick button once with your finger to turn on the monitor. |
|  | | Power off | Press and hold the joystick button once with your finger to turn off the monitor. |
|  |  | Volume control | You can control the volume by moving the joystick button left/right. |
|  |  | Controls screen brightness | You can control the screen's brightness by moving the joystick button up/down. |

Moving and Lifting the Monitor

When moving or lifting the monitor, follow these instructions to prevent the monitor from being scratched or damaged and to ensure safe transportation, regardless of its shape or size.

- Place the monitor in the original box or packing material before attempting to move it.
- Before moving or lifting the monitor, disconnect the power cord and all other cables.
- Hold the bottom and side of the monitor frame firmly. Do not hold the panel itself.
- When holding the monitor, the screen should face away from you to prevent it from being scratched.
- When transporting the monitor, do not expose the monitor to shock or excessive vibration.
- When moving the monitor, keep it upright and never turn the monitor on its side or tilt it sideways.




**CAUTION**

- Avoid touching the monitor screen as much as possible.
 - This may result in damage to the screen or some of the pixels used to create images.
- If you use the monitor panel without the stand base, its joystick button may cause the monitor to become unstable and fall, resulting in damage to the monitor or human injury. In addition, this may cause the joystick button to malfunction.

Installing on a Table

- Lift the monitor and place it on the table in an upright position. Place the monitor at least 100 mm (3.94 inches) away from the wall to ensure sufficient ventilation.



A: 100 mm (3.94 inches)


**CAUTION**

- Unplug the power cord before moving or installing the monitor. There is risk of electric shock.
- Make sure to use the power cord that is provided in the product package and connect it to a grounded power outlet. (Depending on country)

Adjusting the Stand Height

- 1 Place the monitor mounted on the stand base in an upright position.
- 2 Handle the monitor with both hands for safety.

Max. 110.0 mm (4.3 inches)



WARNING




- When adjusting the screen height, do not place your hand on the stand body to avoid injury to your fingers.

Adjusting the Angle


- 1 Place the monitor mounted on the stand base in an upright position.
 - 2 Adjust the angle of the screen.
- The angle of the screen can be adjusted forward or backward from -5° to 15° for a comfortable viewing experience.

WARNING

- To avoid injury to the fingers when adjusting the screen, do not hold the lower part of the monitor's frame as illustrated below.




- Be careful not to touch or press the screen area when adjusting the angle of the monitor.



! NOTE

- The left or right side of the monitor head can be slightly rotated up or down (up to 3°). Adjust the horizontal level of the monitor head.




Using the Kensington Lock

The connector for the Kensington security system is located at the bottom of the monitor.

For more information on installation and usage, refer to the Kensington lock owner's manual or visit the website at <http://www.kensington.com>.

Connect the monitor to a table using the Kensington security system cable.



! NOTE

- The Kensington security system is optional. You can obtain optional accessories from most electronics stores.

Installing the Wall Mount Plate

This monitor meets the specifications for the wall mount plate or other compatible devices.


- 1 Place the screen face down. To protect the monitor panel (screen), cover the surface with a soft cloth or the monitor protection pad included in the product package.
- 2 Remove the four screws tightened on the back of the monitor.
- 3 Place the wall mount plate onto the monitor and align it with the screw holes.
- 4 Tighten the four screws using a screwdriver to fix the plate to the monitor.

! NOTE

- The wall mount plate is sold separately.
- For more information on installation, refer to the wall mount plate's installation guide.
- Be careful not to apply too much force while mounting the wall mount plate as it may cause damage to the screen.

Installing on the Wall

Install the monitor at least 100 mm (3.94 inches) away from the wall and leave about 100 mm (3.94 inches) of space at each side of the monitor to ensure sufficient ventilation. Detailed installation instructions can be obtained from your local retail store. Alternatively, please refer to the manual for how to install and set up a tilting wall mounting bracket.




A: 100 mm (3.94 inches)

To install the monitor to a wall, attach a wall mounting bracket (optional) to the back of the monitor.

Make sure that the wall mounting bracket is securely fixed to the monitor and to the wall.

- 1 If you use screws longer than the standard length, it may damage the inside of the product.
- 2 A non-VESA standard screw may damage the product and cause the monitor to fall. LG Electronics is not liable for any accidents relating to the use of non-standard screws.

| | |
|------------------------------------|--|
| Wall Mount (mm) | 100 x 100 |
| Standard screw | M4 x L10 |
| Number of screws | 4 |
| Wall Mount Plate (Optional) | LSW 149  |


NOTE

- Use the screws specified by VESA standards.
- The wall mount kit includes the installation guide and all necessary parts.
- The wall mounting bracket is optional. You can obtain optional accessories from your local dealer.
- The length of the screw may differ for each wall mounting bracket. Be sure to use the proper length.
- For more information, please refer to the user manual for the wall mounting bracket.

CAUTION

- Unplug the power cord before moving or installing the monitor to avoid electric shock.
- Installing the monitor on the ceiling or on a slanted wall may result in the monitor falling off, which could lead to injury. Use an authorized LG wall mount and contact the local dealer or qualified personnel.
- Applying excessive force when tightening screws may cause damage to the monitor. Damage caused in this way will not be covered by the product warranty.

- Use the wall mounting bracket and screws that conform to VESA standards. Damage caused by the use or misuse of inappropriate components will not be covered by the product warranty.
- When measured from the back of the monitor, the length of each installed screw must be 8 mm (0.3 inches) or less.



USING THE MONITOR

- Illustrations in this manual may differ from the actual product. Press the joystick button, go to **Settings** → **Input**, and then select the input option.



CAUTION

- Do not press the screen for a prolonged time. This may cause image distortion.
- Do not display a still image on the screen for a prolonged time. This may cause image retention. Use a screensaver if possible.



NOTE

- When connecting the power cord to the outlet, use a grounded (3-hole) power strip or a grounded power outlet.
- The monitor may flicker when turned on in an area where the temperature is low. This is normal.
- Sometimes red, green, or blue spots may appear on the screen. This is normal.

Connecting to a PC

- This monitor supports the *Plug and Play feature.
- * Plug and Play: A feature that allows you to add a device to your computer without having to reconfigure anything or install any manual drivers.

HDMI Connection

Transmits digital video and audio signals from your PC to the monitor.



CAUTION

- Using a DVI to HDMI / DP (DisplayPort) to HDMI cable may cause compatibility issues.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- Recommended HDMI cable types
 - Ultra High Speed HDMI®/™ cable

DisplayPort Connection

Transmits digital video and audio signals from your PC to the monitor.

NOTE

- There may be no video or audio output depending on the DP (DisplayPort) version of the PC.
- If you are using a Mini DisplayPort output graphics card, use a Mini DP to DP (Mini DisplayPort to DisplayPort) cable or gender that supports DisplayPort1.4. (sold separately)

USB-C connection (Only for 45GR75DC)

Transmits digital video and audio signals from your PC to the monitor.

NOTE

- PD (Power Delivery) and DP Alternate Mode (DP over USB-C) are supported via USB-C Port.
- Features may not work properly depending on the connected device's specifications and the environment.
- USB-C port is not for the monitor power source but for a PC power source. Connect adapter to supply power to the monitor.

Connecting AV Devices

HDMI Connection

HDMI transmits digital video and audio signals from your AV device to the monitor.

NOTE

- Using a DVI to HDMI / DP (DisplayPort) to HDMI cable may cause compatibility issues.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- Recommended HDMI cable types
 - Ultra High Speed HDMI®/™ cable

Connecting Peripherals

USB Device connection

The USB port on the product functions as a USB hub.

To use USB 3.0, connect the A-B type USB 3.0 cable of the product to the PC.
Peripheral devices connected to the USB IN port can be controlled from the PC.

! NOTE

- It is recommended you install all Windows Updates to keep your Windows up-to-date before connecting to the product for use.
- Peripheral devices are sold separately.
- A keyboard, mouse, or USB device can be connected to the USB port.
- The charging speed may vary depending on the device.
- To use USB Downstream port of monitor, user must connect Upstream port of monitor to Host PC using USB C-C or USB C-A cable.
- When the USB C-C cable is connected between Upstream port of monitor and Host PC, the Downstream port of monitor support USB 2.0 device.
- When the USB C-A cable is connected between Upstream port of monitor and Host PC, the Downstream port of monitor support USB 3.0 device. However, Host PC must support USB 3.0 function.

! CAUTION

Cautions When Using a USB Device

- A USB device with an automatic recognition program installed, or that uses its own driver, may not be recognized.
- Some USB devices may not be supported or may not work properly.
- It is recommended to use a USB hub or hard disk drive with power supplied. (If the power supply is not adequate, the USB device may not be recognized properly.)

Connecting Headphones


Connect peripherals to the monitor via the headphones port.

! NOTE

- Peripheral devices are sold separately.
- If you use angled earphones, it may cause a problem with connecting another external device to the monitor. Therefore, it is recommended to use straight earphones.




Angled



Straight
(Recommend)

- Depending on the audio settings of the PC and external device, headphones and speaker functions may be limited.



- Please connect the USB A to B cable to use a microphone function with headphones equipped with a microphone.


USER SETTINGS




! NOTE

- Your monitor's OSD (On Screen Display) may differ slightly from that shown in this manual.
- When **Beep Guide** is activated, pressing the joystick button will take you to **Settings** right away.


Activating the Main Menu

- Press the joystick button on the bottom of the monitor.
- Move the joystick up/down (▲ / ▼) and left/right (◀ / ▶) to set the options.
- Press the joystick button once more to exit the main menu.



| Button | Menu Status | Description |
|---|----------------------|--|
|  | Main menu disabled | Enables the main menu. |
| | Main menu enabled | Enters the Settings feature. (Holding down the button to turn off the monitor. You can turn off the monitor this way at any time, including when the OSD is on.) |
|  | ◀ Main menu disabled | Adjusts the monitor volume level. |
| | ◀ Main menu enabled | Enters the Input feature. |
| | ▶ Main menu disabled | Adjusts the monitor volume level. |
| | ▶ Main menu enabled | Enters the Game Mode feature. |
|  | ▲ Main menu disabled | Enters the Accessibility menu. |
| | ▲ Main menu enabled | Turns off the monitor. |
| | ▼ Main menu disabled | Enters the Accessibility menu. |
| | ▼ Main menu enabled | Exits the main menu. |

Main Menu Features



| Main Menu | Description |
|------------------|---------------------------------|
| Input | Sets input mode. |
| Power Off | Turns off the monitor. |
| Settings | Configures the screen settings. |
| Game Mode | Sets the game mode for gaming. |
| Exit | Exits the main menu. |

User Settings

Menu Settings

- 1 To view the OSD menu, press the joystick button at the bottom of the monitor and then enter the **Settings**.
- 2 Configure the options by moving the joystick up/down/left/right.
- 3 To return to the upper menu or set other menu items, move the joystick to ◀ or pressing (⏻) it.
- 4 If you want to exit the OSD menu, move the joystick to ◀ until you exit.



Game Mode



Game Adjust



Picture Adjust



Input





General


Game Mode on SDR(Non-HDR)signal.

| Settings > Game Mode | | Description |
|----------------------|----------------|---|
| Game Mode | Gamer 1 | In this mode, users can customize elements including game-related options. |
| | Gamer 2 | Gamer 1 and Gamer 2 picture modes allow you to save two sets of customized display settings, including game-related setup options. |
| | FPS | This mode is optimized for FPS games. It is suitable for very dark FPS games. |
| | RTS | This mode is optimized for RTS games. |
| | Vivid | Optimized the screen for vivid colors. |
| | Reader | Optimizes the screen for viewing documents. You can brighten the screen in the OSD menu. |
| | HDR Effect | Optimizes the screen for high dynamic range. |
| | sRGB | A standard RGB color space for the monitor and printer. |
| | Color Weakness | This mode is for users who cannot distinguish between red and green. It enables users with color weakness to easily distinguish between the two colors. |

Game Mode on HDR signal.


| Settings > Game Mode | | Description |
|----------------------|---|--|
| Game Mode | Gamer 1 | In this mode, users can customize elements including game-related options. |
| | Gamer 2 | Gamer 1 and Gamer 2 picture modes allow you to save two sets of customized display settings, including game-related setup options. |
| | FPS | This mode is optimized for FPS games. It is suitable for very dark FPS games. |
| | RTS | This mode is optimized for RTS games. |
| | Vivid | Optimized the screen for vivid colors. |
| |  NOTE <ul style="list-style-type: none"> • HDR content may not be operated properly depending on the Windows10 OS setting. Please check the HDR On / Off setting of Windows. • When the HDR function is turned on, the characters or picture quality may be poor according to Graphic card performance. • While the HDR function is on, screen flickering or cracking may occur when changing the monitor input or power on/off according to Graphic card performance. • For information about whether the graphics card and game support HDR, visit their manufacture's website. | |

| Settings > Game Adjust | | Description | |
|------------------------|-------------------------|---|--|
| Game Adjust | Adaptive-Sync / VRR | Provides seamless and natural images by synchronizing the vertical frequency of the input signal with that of the output signal.  CAUTION <ul style="list-style-type: none"> Supported Interface: DisplayPort, USB-C (Adaptive-Sync) (Only for 45GR75DC), HDMI (Variable Refresh Rate). Supported Graphic Card: A graphic card that supports AMD's FreeSync is necessary. Supported Version: Make sure to update the graphic card to the latest driver. For more information and requirement, refer to AMD website (www.amd.com). | |
| | | Extended | Enables wider frequency range of Adaptive-Sync/VRR function than basic mode. The screen may flicker during the game play. |
| | | Basic | Enables basic frequency range of Adaptive-Sync/VRR function. |
| | | Off | Adaptive-Sync/VRR function off. |
| | Black Stabilizer | You can control the black contrast to have better visibility in dark scenes. You can easily distinguish objects on dark game screens. | |


| | | | | |
|-------------|---------------|---|---|--|
| Game Adjust | Response Time | Sets a response time for displayed pictures based on the speed of the screen. For a normal environment, it is recommended that you use Fast . For a fast-moving picture, it is recommended that you use Faster . Once Faster Mode is selected, Motion Blur may occur depending on the content. | | |
| | | Faster | Sets the response time to Faster. | |
| | | Fast | Sets the response time to Fast. | |
| | | Normal | Sets the response time to Normal. | |
| | | Off | Does not use the response time improvement feature. | |
| | Crosshair | Crosshair provides a mark on the center of the screen for First Person Shooter (FPS) games. Users can select the Crosshair that fits their gaming environment among four different Crosshairs. | | |
| | FPS Counter | On | The indicator is displayed on the upper left of the screen. It will reflect the actual frame rate that is received at the input. You can also adjust the position of FPS Counter: (upper left / upper right / lower right / lower left) | |
| | | Off | Does not use the FPS Counter feature. | |
| | |  NOTE <ul style="list-style-type: none"> • FPS Counter and Crosshair feature can not be used at the same time. | | |
| | Game Reset | Returns game to the default settings. | | |
| | | No | Cancel the select. | |
| | | Yes | Returns to the default settings. | |

| Settings > Picture Adjust | | Description | |
|---------------------------|--------------------|--|---|
| Picture Adjust | Brightness | Adjusts the brightness of the screen. | |
| | Contrast | Adjusts the contrast of the screen. | |
| | Sharpness | Adjusts the sharpness of the screen. | |
| | Gamma | Mode 1, Mode 2, Mode 3 | The higher the gamma value, the darker the image becomes. Likewise, the lower the gamma value, the lighter the image becomes. |
| | | Mode 4 | If you do not need to adjust the gamma settings, select Mode 4. |
| | Color Temp | Custom | The user can adjust it to red, green, or blue by customization. |
| | | Warm | Sets the screen color to a reddish tone. |
| | | Medium | Sets the screen color to between a red and blue tone. |
| | | Cool | Sets the screen color to a bluish tone. |
| | Manual | The user can fine - tune the color temperature. | |
| | R/G/B | You can customize the picture color using Red , Green , and Blue colors. | |
| | Six Color | | Meets the user requirements for colors by adjusting the hue and saturation of the six colors (Red, Green, Blue, Cyan, Magenta and Yellow) and then saving the settings. |
| | | Hue | Adjusts the tone of the screen colors. |
| | | Saturation | Adjusts the saturation of the screen colors. The lower the value, the less saturated and brighter the colors become. The higher the value, the more saturated and darker the colors become. |
| | Black Level | | Sets the offset level (for HDMI only). <ul style="list-style-type: none"> Offset: as a reference for a video signal, this is the darkest color the monitor can display. |
| High | | Keeps the current contrast ratio of the screen. | |
| Low | | Lowers the black levels and raises the white levels from the current contrast ratio of the screen. | |


| | | | |
|----------------|---------------|--|---|
| Picture Adjust | Local Dimming | Maximizes the contrast ratio by making the bright areas of the screen brighter and the dark areas of the screen darker. Turning this option off may increase energy consumption. | |
| | | Faster | Sets the local dimming to faster. |
| | | Fast | Sets the local dimming to fast. |
| | | Normal | Sets the local dimming to normal. |
| | | Off | Does not use the local dimming improvement feature. |
| | Picture Reset | Do you want to reset your picture settings? | |
| | | No | Cancel the select. |
| | | Yes | Returns to the default settings. |

| Settings > Input | | Description | |
|------------------|--|--|--|
| Input | Input List | Selects the input mode. | |
| | Aspect Ratio | Adjusts the aspect ratio of the screen. | |
| | | Full Wide | Displays the video in widescreen, regardless of the video signal input. |
| | | Original | Displays video according to the aspect ratio of the video signal input. |
| | | Just Scan | The aspect ratio is not adjusted from the original. |
| | | Cinema 1 | Enlarges the screen with an aspect ratio of 32:9. |
| | | Cinema 2 | Enlarges the screen with an aspect ratio of 32:9, including the black box at the bottom for subtitles. |
| |  NOTE <ul style="list-style-type: none"> The display may look the same for Full Wide and Original options at the recommended resolution. (5120 x 1440) | | |
| | Auto Input Switch | When automatic input switch is set to On , display will automatically switch to new input when connected. | |
| | | On | Enables Auto Input Switch . |
| Off | | Disables Auto Input Switch . | |

| | | | | | | | |
|----------------------|--|--|--------|-------------------|--------|----|-------|
| Input | PBP / PIP | You can select the various PBP or PIP combination. USB-C combination only for 45GR75DC. | | | | | |
| | | PBP / PIP Connection | | Sub Screen | | | |
| | | | | HDMI 1 | HDMI 2 | DP | USB-C |
| | | Main Screen | HDMI 1 | - | 0 | 0 | 0 |
| | | | HDMI 2 | 0 | - | 0 | 0 |
| | DP | | 0 | 0 | - | 0 | |
| | USB-C | | 0 | 0 | 0 | - | |
| | PIP Size | Sets the size of the PIP Sub window. ([Large] / [Small]) | | | | | |
| | PIP Position | Sets the position of the PIP Sub window. (Bottom Right / Bottom Left / Top Left / Top Right) | | | | | |
| Screen Switch | Switches the main screen/sub-screen in PBP/PIP mode. | | | | | | |
| Sound Switch | Switch the main screen/sub-screen sound in PBP/PIP mode. | | | | | | |

| Settings > General | | Description | |
|--------------------|---|--|---|
| General | Language | Sets the menu screen to the desired language. | |
| | USB Selection (Only for 45GR75DC) | Select the USB upstream cable connection port to use USB hub of the monitor. | |
| | USB Switch (Only for 45GR75DC) | Switch the USB device connected to the monitor to another input source. | |
| | USB-C Option (Only for 45GR75DC) | Set the USB-C settings to be optimized for screen resolution or USB data rate. | |
| | | High Resolution | Set display resolution as priority. |
| | | High Data Speed | Set data speed as priority. |
| |  NOTE <ul style="list-style-type: none"> High Data Speed setting supports USB 3.0 data. When connecting with legacy devices, the resolution may be lowered. | | |
| | User-defined Key 1 | You can customise the main menu to access your preferred menu easily. | |
| | User-defined Key 2 | User-defined Key 1 and User-defined Key 2 appear at the left/right of the main menu. | |
| | DTS Headphone:X | Enables the realization of three-dimensional sound with headphones or earphone. | |
| | | Game | This mode is optimized for Game. |
| | | Entertainment | This mode is optimized for Entertainment. |
| | | Sports | This mode is optimized for Sports. |
| Off | | Disables DTS Headphone:X function. | |

| | | | |
|---------|-----------------------------|--|--|
| General | SMART ENERGY SAVING | High | Saves energy using the high-efficiency SMART ENERGY SAVING feature. |
| | | Low | Saves energy using the low-efficiency SMART ENERGY SAVING feature. |
| | | Off | Disables the SMART ENERGY SAVING feature. |
| | Deep Sleep Mode | When Deep sleep mode is enabled, power consumption is minimized while the monitor is in standby mode. | |
| | | On | Enables Deep sleep Mode . |
| | | Off | Disables Deep sleep Mode . |
| | Power LED | Turns the power LED on the bottom of the monitor on or off. | |
| | | On | The power LED turns on automatically. |
| | | Off | The power LED turns off. |
| | Automatic Standby | Feature that automatically turns off the monitor when there is no movement on the screen for a period of time. You can set a timer for the auto-off function. (8H , 6H , 4H and Off) | |
| | Input Compatibility Version | Please set the Input Compatibility Version to match the version of the connected external device. | |
| | | HDMI | 2.1(PC)/2.1(AV)/1.4 If you want to use the HDR, select the Input Compatibility Version to 2.1(PC) or 2.1(AV). |
| | | DisplayPort | 1.4(DSC)/1.4/1.2 |
| | | USB-C (Only for 45GR75DC) | If you want to use the HDR, select the Input Compatibility Version to 1.4(DSC) or 1.4. |
| | Buzzer | This feature lets you set the sound generated from Buzzer when your monitor powers on. | |
| On | | Enables your monitor's Buzzer . | |
| Off | | Disables your monitor's Buzzer . | |

| | | | |
|---------|---------------------------|--|----------------------------------|
| General | OSD Lock | This feature disables the configuration and adjustment of menus. | |
| | | On | Enables OSD Lock . |
| | | Off | Disables OSD Lock . |
| | |  NOTE <ul style="list-style-type: none"> All features are disabled except Brightness, Contrast in Picture Adjust, Input, OSD Lock and Information in General. | |
| | Information | The display information will be shown the Total Power On Time, Resolution. | |
| | Reset to Initial Settings | Do you want to reset your settings? | |
| | | No | Cancel the reset. |
| | | Yes | Returns to the default settings. |

TROUBLESHOOTING

| Nothing is displayed on the screen. | |
|---|--|
| Is the monitor's power cord plugged in? | <ul style="list-style-type: none"> • Check if the power cord is correctly plugged into the power outlet. |
| Is the power LED on? | <ul style="list-style-type: none"> • Check the power cable connection and press the power button. |
| Is the power on and the power LED displaying red? | <ul style="list-style-type: none"> • Check that the connected input is enabled (Settings > Input). |
| Is the power LED blinking? | <ul style="list-style-type: none"> • If the monitor is in sleep mode, move the mouse, or press any key on the keyboard, to switch the display on. • Check if the computer is turned on. |
| Is the " The screen is not currently set to the recommended resolution. " message being displayed? | <ul style="list-style-type: none"> • This occurs when signals transferred from the PC (graphics card) are out of the recommended horizontal or vertical frequency range of the monitor. Please see the Product Specification section of this manual to set the appropriate frequency. |
| Is the " No Signal " message being displayed? | <ul style="list-style-type: none"> • This is displayed when the signal cable between the PC and the monitor is missing or disconnected. Check the cable and reconnect it. |
| Have you installed the display driver? | <ul style="list-style-type: none"> • Be sure to install the display driver from our web site: http://www.lg.com. • Make sure to check if the graphics card supports Plug and Play function. |

| Some features are disabled. | |
|--|--|
| Are some functions not available when you press the Menu button? | <ul style="list-style-type: none"> • The OSD is locked. Go to Settings > General and set OSD Lock to Off. |

| The screen retains an image. | |
|--|---|
| Does image sticking occur even when the monitor is turned off? | <ul style="list-style-type: none"> • Displaying a still image for a prolonged time may cause damage to the screen, resulting in the retention of the image. • To extend the lifetime of the monitor, use a screensaver. |

| Screen display is unstable and shaky. / Images displayed on the monitor leave shadow trails. | |
|--|---|
| Did you select the appropriate resolution? | <ul style="list-style-type: none"> • If the selected resolution is HDMI 1080i 60/50 Hz (interlaced), the screen may be flickering. Change the resolution to 1080p or the recommended resolution. |

NOTE

- Vertical Frequency: In order to display an image, the screen must be refreshed dozens of times per second, like a fluorescent lamp. The number of times the screen is refreshed per second is called vertical frequency, or refresh rate, and is represented by Hz.
- Horizontal Frequency: The time it takes to display one horizontal line is called the horizontal cycle. If 1 is divided by the horizontal interval, the result is the number of horizontal lines displayed per second. This is called horizontal frequency and is represented by kHz.
- Check if the graphics card's resolution or frequency is within the range allowed by the monitor and set it to the recommended (optimal) resolution **Control Panel > Display > Settings** in Windows. (The settings may differ depending on the operating system (OS) you use.)
- Not setting the graphics card to the recommended (optimal) resolution may result in blurred text, a dimmed screen, a truncated display area or misalignment of the display.
- The setting methods may be different depending on the computer or operating system, and some resolutions may not be available depending on the performance of the graphics card. If this is the case, contact the manufacturer of the computer or graphics card for assistance.

| The display color is abnormal. | |
|---|---|
| Does the display appear discolored (16 colors)? | <ul style="list-style-type: none"> Set the color to 24 bit (true color) or higher. In Windows, go to Control Panel > Display > Settings > Color Quality. (The settings may differ depending on the operating system (OS) you use.) |
| Does the display color appear unstable or monochrome? | <ul style="list-style-type: none"> Check if the signal cable is connected properly. Reconnect the cable or reinsert the PC's graphics card. |
| Are there spots on the screen? | <ul style="list-style-type: none"> When using the monitor, pixilated spots (red, green, blue, white, or black) may appear on the screen. This is normal for an LCD screen. It is not an error, nor is it related to the monitor's performance. |

| No sound from the headphone port. | |
|--|--|
| Are images displayed using DP (DisplayPort) or HDMI input without sound? | <ul style="list-style-type: none"> Make sure that the headphone port connections are made properly. Try increasing the volume with the joystick. Set the audio output of the PC to the monitor you are using. On Microsoft Windows, go to Control Panel > Hardware and Sound > Sound > set the Monitor as default device. (The settings may differ depending on the operating system (OS) you use.) |

PRODUCT SPECIFICATION

| | | | |
|--------------------------|-----------------------------|---|-----------------------------------|
| LCD Screen | Color Depth | HDMI | 10-bit color is supported. |
| | | DP (DisplayPort) | 10-bit color is supported. |
| | | USB-C (Only for 45GR75DC) | 10-bit color is supported. |
| Resolution | Max Resolution | 5120 x 1440 @ 200 Hz | |
| | Recommended Resolution | 5120 x 1440 @ 200 Hz | |
| Power Sources | Power Rating | 45GR75DC | 19.5 V --- 10.0 A |
| | | 45GR65DC | 19 V --- 5.0 A |
| | Power Consumption (Typical) | On mode: 80 W (Typical)* Sleep Mode (Standby Mode) : ≤ 0.5 W Off Mode: ≤ 0.3 W | |
| AC/DC Adapter | 45GR75DC | ACC-LATP2, manufactured by SHENZHEN HONOR ELECTRONIC Or AD10630LF, manufactured by PI Electronics (H.K.) Ltd. Output: 19.5 V --- 10.8 A | |
| | 45GR65DC | ADS-110CL-19-3 190110G, manufactured by SHENZHEN HONOR ELECTRONIC Or ADS-120QL-19A-3 190110E, manufactured by SHENZHEN HONOR ELECTRONIC Output: 19 V --- 5.79 A | |
| Environmental Conditions | Operating Conditions | Temperature | 0 °C to 40 °C (32 °F to 104 °F) |
| | | Humidity | Less than 80 % |
| | Storing Conditions | Temperature | -20 °C to 60 °C (-4 °F to 140 °F) |
| | | Humidity | Less than 85 % |

| | | | |
|----------------------------|---------------------------------------|--|-------------------|
| Dimensions | Monitor Size (Width x Height x Depth) | | |
| | With Stand | 1083.7 x 559.4 x 328.3 (mm) 42.6 x 22.0 x 12.9 (inches) | |
| | Without Stand | 1083.7 x 332.6 x 163.8 (mm) 42.6 x 13.0 x 6.4 (inches) | |
| Weight (Without Packaging) | 45GR75DC | With Stand | 8.8 kg (19.4 lbs) |
| | | Without Stand | 6.2 kg (13.6 lbs) |
| | 45GR65DC | With Stand | 8.7 kg (19.1 lbs) |
| | | Without Stand | 6.1 kg (13.4 lbs) |

Specifications are subject to change without notice.

The ~ symbol means alternating current, and the — symbol means direct current.

The Power Consumption level can be different by operating condition and monitor setting.

* The On mode power consumption is measured with LGE test standard (Full White pattern, Maximum resolution).

** The monitor goes to the Sleep Mode in a couple of minutes (Max 5 minutes).

Factory Support Mode

DisplayPort/USB-C (Only for 45GR75DC)

| Resolution | Horizontal Frequency (kHz) | Vertical Frequency (Hz) | Polarity (H/V) | Remarks |
|-------------|----------------------------|-------------------------|----------------|-----------|
| 640 x 480 | 31.469 | 59.94 | -/- | |
| 800 x 600 | 37.879 | 60.317 | +/+ | |
| 1024 x 768 | 48.363 | 60.004 | -/- | |
| 1280 x 720 | 45 | 60 | +/+ | |
| 1280 x 1024 | 79.976 | 75.025 | +/+ | |
| 1920 x 1080 | 67.5 | 60 | +/+ | |
| 720 x 480 | 61.08 | 119.999 | +/- | PIP(480P) |
| 1280 x 720 | 91.493 | 119.912 | +/- | PIP(720P) |
| 1680 x 1440 | 182.88 | 119.922 | +/- | PBP(11:9) |
| 3840 x 1080 | 113.25 | 99.956 | +/- | |
| 5120 x 1440 | 88.826 | 59.977 | +/- | |
| 2560 x 1440 | 182.996 | 119.998 | +/- | PBP(16:9) |
| 3840 x 1080 | 137.25 | 119.974 | +/- | |
| 5120 x 1440 | 111.884 | 74.99 | +/- | 1.2 |
| 3440 x 1440 | 181.944 | 119.937 | +/- | PBP(21:9) |
| 5120 x 1440 | 182.955 | 119.97 | +/- | 1.4 |
| 5120 x 1440 | 222.159 | 143.979 | +/- | |
| 5120 x 1440 | 317.188 | 199.992 | +/- | 1.4(DSC) |
| 1680 x 1440 | 88.859 | 59.999 | +/- | |
| 2560 x 1440 | 88.787 | 59.951 | +/- | |
| 3440 x 1440 | 88.819 | 59.973 | +/- | |

HDMI

| Resolution | Horizontal Frequency (kHz) | Vertical Frequency (Hz) | Polarity (H/V) | Remarks |
|-------------|----------------------------|-------------------------|----------------|---------------|
| 640 x 480 | 31.469 | 59.94 | -/- | |
| 800 x 600 | 37.879 | 60.317 | +/+ | |
| 1024 x 768 | 48.363 | 60.004 | -/- | |
| 1280 x 720 | 45 | 60 | +/+ | |
| 1280 x 1024 | 79.976 | 75.025 | +/+ | |
| 1920 x 1080 | 67.5 | 60 | +/+ | |
| 720 x 480 | 61.08 | 119.999 | +/- | PIP(480P) |
| 1280 x 720 | 91.493 | 119.912 | +/- | PIP(720P) |
| 1680 x 1440 | 88.859 | 59.999 | +/- | |
| 2560 x 1440 | 88.787 | 59.951 | +/- | |
| 3440 x 1440 | 73.681 | 49.987 | +/- | 1.4_PBP(21:9) |
| 3840 x 1080 | 66.625 | 59.968 | +/- | 1.4 |
| 1680 x 1440 | 182.88 | 119.922 | +/- | PBP(11:9) |
| 5120 x 1440 | 88.826 | 59.977 | +/- | |
| 2560 x 1440 | 182.996 | 119.998 | +/- | PBP(16:9) |
| 3440 x 1440 | 150.972 | 99.982 | +/- | 2.0_PBP(21:9) |
| 3840 x 1080 | 137.25 | 119.974 | +/- | 2.1(AV) |
| 5120 x 1440 | 182.955 | 119.97 | +/- | |
| 5120 x 1440 | 222.159 | 143.979 | +/- | |
| 5120 x 1440 | 317.2 | 200 | +/- | 2.1(PC) |

HDMI Timing (Video)

| Preset Mode | Horizontal Frequency (kHz) | Vertical Frequency (Hz) | Remarks |
|-------------|----------------------------|-------------------------|---------|
| 480P | 31.5 | 60 | |
| 720P | 45 | 60 | |
| 1080P | 67.5 | 60 | |
| 1080P | 135 | 120 | |
| 2160P | 135 | 60 | |
| 2160P | 255 | 120 | |

Power LED

| Mode | LED Color |
|---------------------------|-------------------------|
| On Mode | Red (For a few seconds) |
| Sleep Mode (Standby Mode) | Off |
| Off Mode | Off |

Beep Guide

45GR75DC

| Menu | Location |
|--|-----------------|
| Game Mode | 1 |
| Game Mode - Gamer 1 | 1 1 |
| Game Mode - Gamer 2 | 1 2 |
| Game Mode - FPS | 1 3 |
| Game Mode - RTS | 1 4 |
| Game Mode - Vivid | 1 5 |
| Game Mode - Reader | 1 6 |
| Game Mode - HDR Effect | 1 7 |
| Game Mode - sRGB | 1 8 |
| Game Mode - Color Weakness | 1 9 |
| Game Adjust | 2 |
| Game Adjust - VRR / Adaptive-Sync | 2 1 |
| Game Adjust - VRR / Adaptive-Sync - Extended | 2 1 1 |
| Game Adjust - VRR / Adaptive-Sync - Basic | 2 1 2 |
| Game Adjust - VRR / Adaptive-Sync - Off | 2 1 3 |
| Game Adjust - Black Stabilizer | 2 2 |
| Game Adjust - Black Stabilizer | 2 2 1 Slider |
| Game Adjust - Response Time | 2 3 |
| Game Adjust - Response Time - Faster | 2 3 1 |
| Game Adjust - Response Time - Fast | 2 3 2 |
| Game Adjust - Response Time - Normal | 2 3 3 |
| Game Adjust - Response Time - Off | 2 3 4 |
| Game Adjust - Crosshair | 2 4 |

| Menu | Location |
|---------------------------------------|-----------------|
| Game Adjust - Crosshair - Red Cross | 2 4 1 |
| Game Adjust - Crosshair - Green Cross | 2 4 2 |
| Game Adjust - Crosshair - Red Dot | 2 4 3 |
| Game Adjust - Crosshair - Green Dot | 2 4 4 |
| Game Adjust - Crosshair - Off | 2 4 5 |
| Game Adjust - FPS Counter | 2 5 |
| Game Adjust - FPS Counter - On | 2 5 1 |
| Game Adjust - FPS Counter - Off | 2 5 2 |
| Game Adjust - Game Reset | 2 6 |
| Game Adjust - Game Reset - No | 2 6 1 |
| Game Adjust - Game Reset - Yes | 2 6 2 |
| Picture Adjust | 3 |
| Picture Adjust - Brightness | 3 1 |
| Picture Adjust - Brightness | 3 1 1 Slider |
| Picture Adjust - Contrast | 3 2 |
| Picture Adjust - Contrast | 3 2 1 Slider |
| Picture Adjust - Sharpness | 3 3 |
| Picture Adjust - Sharpness | 3 3 1 Slider |
| Picture Adjust - Gamma | 3 4 |
| Picture Adjust - Gamma - Mode 1 | 3 4 1 |
| Picture Adjust - Gamma - Mode 2 | 3 4 2 |
| Picture Adjust - Gamma - Mode 3 | 3 4 3 |
| Picture Adjust - Gamma - Mode 4 | 3 4 4 |

| Menu | Location |
|---|-------------------|
| Picture Adjust - Color Temp | 3 5 |
| Picture Adjust - Color Temp - Custom | 3 5 1 |
| Picture Adjust - Color Temp - Warm | 3 5 2 |
| Picture Adjust - Color Temp - Medium | 3 5 3 |
| Picture Adjust - Color Temp - Cool | 3 5 4 |
| Picture Adjust - Color Temp - Manual | 3 5 5 |
| Picture Adjust - Color Temp - Manual | 3 5 5 1 Slider |
| Picture Adjust - R/G/B | 3 6 |
| Picture Adjust - R/G/B - Red | 3 6 1 |
| Picture Adjust - R/G/B - Red | 3 6 1 1 Slider |
| Picture Adjust - R/G/B - Green | 3 6 2 |
| Picture Adjust - R/G/B - Green | 3 6 2 1 Slider |
| Picture Adjust - R/G/B - Blue | 3 6 3 |
| Picture Adjust - R/G/B - Blue | 3 6 3 1 Slider |
| Picture Adjust - Six Color | 3 7 |
| Picture Adjust - Six Color - Red Hue | 3 7 1 |
| Picture Adjust - Six Color - Red Hue | 3 7 1 1 Slider |
| Picture Adjust - Six Color - Red Saturation | 3 7 2 |
| Picture Adjust - Six Color - Red Saturation | 3 7 2 1 Slider |

| Menu | Location |
|---|--------------------|
| Picture Adjust - Six Color - Green Hue | 3 7 3 |
| Picture Adjust - Six Color - Green Hue | 3 7 3 1 Slider |
| Picture Adjust - Six Color - Green Saturation | 3 7 4 |
| Picture Adjust - Six Color - Green Saturation | 3 7 4 1 Slider |
| Picture Adjust - Six Color - Blue Hue | 3 7 5 |
| Picture Adjust - Six Color - Blue Hue | 3 7 5 1 Slider |
| Picture Adjust - Six Color - Blue Saturation | 3 7 6 |
| Picture Adjust - Six Color - Blue Saturation | 3 7 6 1 Slider |
| Picture Adjust - Six Color - Cyan Hue | 3 7 7 |
| Picture Adjust - Six Color - Cyan Hue | 3 7 7 1 Slider |
| Picture Adjust - Six Color - Cyan Saturation | 3 7 8 |
| Picture Adjust - Six Color - Cyan Saturation | 3 7 8 1 Slider |
| Picture Adjust - Six Color - Magenta Hue | 3 7 9 |
| Picture Adjust - Six Color - Magenta Hue | 3 7 9 1 Slider |
| Picture Adjust - Six Color - Magenta Saturation | 3 7 10 |
| Picture Adjust - Six Color - Magenta Saturation | 3 7 10 1 Slider |
| Picture Adjust - Six Color - Yellow Hue | 3 7 11 |

| Menu | Location |
|--|--------------------|
| Picture Adjust - Six Color - Yellow Hue | 3 7 11 1 Slider |
| Picture Adjust - Six Color - Yellow Saturation | 3 7 12 |
| Picture Adjust - Six Color - Yellow Saturation | 3 7 12 1 Slider |
| Picture Adjust - Black Level | 3 8 |
| Picture Adjust - Black Level - High | 3 8 1 |
| Picture Adjust - Black Level - Low | 3 8 2 |
| Picture Adjust - Local Dimming | 3 9 |
| Picture Adjust - Local Dimming - Faster | 3 9 1 |
| Picture Adjust - Local Dimming - Fast | 3 9 2 |
| Picture Adjust - Local Dimming - Normal | 3 9 3 |
| Picture Adjust - Local Dimming - Off | 3 9 4 |
| Picture Adjust - Picture Reset | 3 10 |
| Picture Adjust - Picture Reset - No | 3 10 1 |
| Picture Adjust - Picture Reset - Yes | 3 10 2 |
| Input | 4 |
| Input - Input List | 4 1 |
| Input - Input List - HDMI 1 | 4 1 1 |
| Input - Input List - HDMI 2 | 4 1 2 |
| Input - Input List - DisplayPort | 4 1 3 |
| Input - Input List - USB-C | 4 1 4 |
| Input - Aspect Ratio | 4 2 |
| Input - Aspect Ratio - Full Wide | 4 2 1 |
| Input - Aspect Ratio - Original | 4 2 2 |
| Input - Aspect Ratio - Just Scan | 4 2 3 |
| Input - Aspect Ratio - Cinema 1 | 4 2 4 |

| Menu | Location |
|-------------------------------------|----------|
| Input - Aspect Ratio - Cinema 2 | 4 2 5 |
| Input - Auto Input Switch | 4 3 |
| Input - Auto Input Switch - On | 4 3 1 |
| Input - Auto Input Switch - Off | 4 3 2 |
| Input - PBP/PIP | 4 4 |
| Input - PBP/PIP - Off | 4 4 1 |
| Input - PBP/PIP - Off - HDMI1 | 4 4 1 1 |
| Input - PBP/PIP - Off - HDMI2 | 4 4 1 2 |
| Input - PBP/PIP - Off - DisplayPort | 4 4 1 3 |
| Input - PBP/PIP - Off - USB-C | 4 4 1 4 |
| Input - PBP/PIP - PBP(16:9/16:9) | 4 4 2 |
| Input - PBP/PIP - PBP(21:9/11:9) | 4 4 3 |
| Input - PBP/PIP - PBP(11:9/21:9) | 4 4 4 |
| Input - PBP/PIP - PIP | 4 4 5 |
| Input - PIP Size | 4 5 |
| Input - PIP Size - Small | 4 5 1 |
| Input - PIP Size - Large | 4 5 2 |
| Input - PIP Position | 4 6 |
| Input - PIP Position - Bottom Right | 4 6 1 |
| Input - PIP Position - Bottom Left | 4 6 2 |
| Input - PIP Position - Top Left | 4 6 3 |
| Input - PIP Position - Top Right | 4 6 4 |
| Input - Screen Switch | 4 7 |
| Input - Screen Switch - OK | 4 7 1 |
| Input - Sound Switch | 4 8 |
| Input - Sound Switch - OK | 4 8 1 |
| General | 5 |

| Menu | Location |
|--|----------|
| General - Language | 5 1 |
| General - Language - English | 5 1 1 |
| General - Language - German | 5 1 2 |
| General - Language - French | 5 1 3 |
| General - Language - Spanish | 5 1 4 |
| General - Language - Italian | 5 1 5 |
| General - Language - Swedish | 5 1 6 |
| General - Language - Finnish | 5 1 7 |
| General - Language - Portuguese | 5 1 8 |
| General - Language - Portuguese (Brazil) | 5 1 9 |
| General - Language - Polish | 5 1 10 |
| General - Language - Russian | 5 1 11 |
| General - Language - Turkish | 5 1 12 |
| General - Language - Ukrainian | 5 1 13 |
| General - Language - Chinese | 5 1 14 |
| General - Language - Traditional Chinese | 5 1 15 |
| General - Language - Japanese | 5 1 16 |
| General - Language - Korean | 5 1 17 |
| General - USB Selection | 5 2 |
| General - USB Selection - HDMI 1 - USB-B | 5 2 1 1 |
| General - USB Selection - HDMI 1 - USB-C | 5 2 1 2 |
| General - USB Selection - HDMI 2 - USB-B | 5 2 2 1 |
| General - USB Selection - HDMI 2 - USB-C | 5 2 2 2 |

| Menu | Location |
|---|----------|
| General - USB Selection - DisplayPort - USB-B | 5 2 3 1 |
| General - USB Selection - DisplayPort - USB-C | 5 2 3 2 |
| General - USB Selection - USB-C - USB-B | 5 2 4 1 |
| General - USB Selection - USB-C - USB-C | 5 2 4 2 |
| General - USB Switch | 5 3 |
| General - USB Switch - USB-B | 5 3 1 |
| General - USB Switch - USB-C | 5 3 2 |
| General - USB-C Option | 5 4 |
| General - USB-C Option - High Resolution | 5 4 1 |
| General - USB-C Option - High Data Speed | 5 4 2 |
| General - User-defined Key 1 | 5 5 |
| General - User-defined Key 1 - Input | 5 5 1 |
| General - User-defined Key 1 - Game Mode | 5 5 2 |
| General - User-defined Key 1 - Crosshair | 5 5 3 |
| General - User-defined Key 1 - Black Stabilizer | 5 5 4 |
| General - User-defined Key 1 - Response Time | 5 5 5 |
| General - User-defined Key 1 - FPS Counter | 5 5 6 |
| General - User-defined Key 1 - USB Switch | 5 5 7 |
| General - User-defined Key 1 - PBP/PIP | 5 5 8 |
| General - User-defined Key 2 | 5 6 |

| Menu | Location |
|---|----------|
| General - User-defined Key 2 - Input | 5 6 1 |
| General - User-defined Key 2 - Game Mode | 5 6 2 |
| General - User-defined Key 2 - Crosshair | 5 6 3 |
| General - User-defined Key 2 - Black Stabilizer | 5 6 4 |
| General - User-defined Key 2 - Response Time | 5 6 5 |
| General - User-defined Key 2 - FPS Counter | 5 6 6 |
| General - User-defined Key 2 - USB Switch | 5 6 7 |
| General - User-defined Key 2 - PBP/PIP | 5 6 8 |
| General - DTS Headphone:X | 5 7 |
| General - DTS Headphone:X - Game | 5 7 1 |
| General - DTS Headphone:X - Entertainment | 5 7 2 |
| General - DTS Headphone:X - Sports | 5 7 3 |
| General - DTS Headphone:X - Off | 5 7 4 |
| General - SMART ENERGY SAVING | 5 8 |
| General - SMART ENERGY SAVING - High | 5 8 1 |
| General - SMART ENERGY SAVING - Low | 5 8 2 |
| General - SMART ENERGY SAVING - Off | 5 8 3 |
| General - Deep Sleep Mode | 5 9 |
| General - Deep Sleep Mode - On | 5 9 1 |
| General - Deep Sleep Mode - Off | 5 9 2 |
| General - Power LED | 5 10 |

| Menu | Location |
|---|----------|
| General - Power LED - On | 5 10 1 |
| General - Power LED - Off | 5 10 2 |
| General - Automatic Standby | 5 11 |
| General - Automatic Standby - 8H | 5 11 1 |
| General - Automatic Standby - 6H | 5 11 2 |
| General - Automatic Standby - 4H | 5 11 3 |
| General - Automatic Standby - Off | 5 11 4 |
| General - Input Compatibility Version | 5 12 |
| General - Input Compatibility Version - 2.1(PC) / 1.4(DSC) | 5 12 1 |
| General - Input Compatibility Version - 2.1(AV) / 1.4 | 5 12 2 |
| General - Input Compatibility Version - 1.4 / 1.2 | 5 12 3 |
| General - Buzzer | 5 13 |
| General - Buzzer - On | 5 13 1 |
| General - Buzzer - Off | 5 13 2 |
| General - OSD Lock | 5 14 |
| General - OSD Lock - On | 5 14 1 |
| General - OSD Lock - Off | 5 14 2 |
| General - Information | 5 15 |
| General - Reset to Initial Settings | 5 16 |
| General - Reset to Initial Settings - No | 5 16 1 |
| General - Reset to Initial Settings - Yes | 5 16 2 |

45GR65DC

| Menu | Location |
|--|-----------------|
| Game Mode | 1 |
| Game Mode - Gamer 1 | 1 1 |
| Game Mode - Gamer 2 | 1 2 |
| Game Mode - FPS | 1 3 |
| Game Mode - RTS | 1 4 |
| Game Mode - Vivid | 1 5 |
| Game Mode - Reader | 1 6 |
| Game Mode - HDR Effect | 1 7 |
| Game Mode - sRGB | 1 8 |
| Game Mode - Color Weakness | 1 9 |
| Game Adjust | 2 |
| Game Adjust - VRR / Adaptive-Sync | 2 1 |
| Game Adjust - VRR / Adaptive-Sync - Extended | 2 1 1 |
| Game Adjust - VRR / Adaptive-Sync - Basic | 2 1 2 |
| Game Adjust - VRR / Adaptive-Sync - Off | 2 1 3 |
| Game Adjust - Black Stabilizer | 2 2 |
| Game Adjust - Black Stabilizer | 2 2 1 Slider |
| Game Adjust - Response Time | 2 3 |
| Game Adjust - Response Time - Faster | 2 3 1 |
| Game Adjust - Response Time - Fast | 2 3 2 |
| Game Adjust - Response Time - Normal | 2 3 3 |
| Game Adjust - Response Time - Off | 2 3 4 |
| Game Adjust - Crosshair | 2 4 |
| Game Adjust - Crosshair - Red Cross | 2 4 1 |

| Menu | Location |
|---------------------------------------|-----------------|
| Game Adjust - Crosshair - Green Cross | 2 4 2 |
| Game Adjust - Crosshair - Red Dot | 2 4 3 |
| Game Adjust - Crosshair - Green Dot | 2 4 4 |
| Game Adjust - Crosshair - Off | 2 4 5 |
| Game Adjust - FPS Counter | 2 5 |
| Game Adjust - FPS Counter - On | 2 5 1 |
| Game Adjust - FPS Counter - Off | 2 5 2 |
| Game Adjust - Game Reset | 2 6 |
| Game Adjust - Game Reset - No | 2 6 1 |
| Game Adjust - Game Reset - Yes | 2 6 2 |
| Picture Adjust | 3 |
| Picture Adjust - Brightness | 3 1 |
| Picture Adjust - Brightness | 3 1 1 Slider |
| Picture Adjust - Contrast | 3 2 |
| Picture Adjust - Contrast | 3 2 1 Slider |
| Picture Adjust - Sharpness | 3 3 |
| Picture Adjust - Sharpness | 3 3 1 Slider |
| Picture Adjust - Gamma | 3 4 |
| Picture Adjust - Gamma - Mode 1 | 3 4 1 |
| Picture Adjust - Gamma - Mode 2 | 3 4 2 |
| Picture Adjust - Gamma - Mode 3 | 3 4 3 |
| Picture Adjust - Gamma - Mode 4 | 3 4 4 |
| Picture Adjust - Color Temp | 3 5 |
| Picture Adjust - Color Temp - Custom | 3 5 1 |

| Menu | Location |
|---|-------------------|
| Picture Adjust - Color Temp - Warm | 3 5 2 |
| Picture Adjust - Color Temp - Medium | 3 5 3 |
| Picture Adjust - Color Temp - Cool | 3 5 4 |
| Picture Adjust - Color Temp - Manual | 3 5 5 |
| Picture Adjust - Color Temp - Manual | 3 5 5 1 Slider |
| Picture Adjust - R/G/B | 3 6 |
| Picture Adjust - R/G/B - Red | 3 6 1 |
| Picture Adjust - R/G/B - Red | 3 6 1 1 Slider |
| Picture Adjust - R/G/B - Green | 3 6 2 |
| Picture Adjust - R/G/B - Green | 3 6 2 1 Slider |
| Picture Adjust - R/G/B - Blue | 3 6 3 |
| Picture Adjust - R/G/B - Blue | 3 6 3 1 Slider |
| Picture Adjust - Six Color | 3 7 |
| Picture Adjust - Six Color - Red Hue | 3 7 1 |
| Picture Adjust - Six Color - Red Hue | 3 7 1 1 Slider |
| Picture Adjust - Six Color - Red Saturation | 3 7 2 |
| Picture Adjust - Six Color - Red Saturation | 3 7 2 1 Slider |
| Picture Adjust - Six Color - Green Hue | 3 7 3 |
| Picture Adjust - Six Color - Green Hue | 3 7 3 1 Slider |

| Menu | Location |
|---|--------------------|
| Picture Adjust - Six Color - Green Saturation | 3 7 4 |
| Picture Adjust - Six Color - Green Saturation | 3 7 4 1 Slider |
| Picture Adjust - Six Color - Blue Hue | 3 7 5 |
| Picture Adjust - Six Color - Blue Hue | 3 7 5 1 Slider |
| Picture Adjust - Six Color - Blue Saturation | 3 7 6 |
| Picture Adjust - Six Color - Blue Saturation | 3 7 6 1 Slider |
| Picture Adjust - Six Color - Cyan Hue | 3 7 7 |
| Picture Adjust - Six Color - Cyan Hue | 3 7 7 1 Slider |
| Picture Adjust - Six Color - Cyan Saturation | 3 7 8 |
| Picture Adjust - Six Color - Cyan Saturation | 3 7 8 1 Slider |
| Picture Adjust - Six Color - Magenta Hue | 3 7 9 |
| Picture Adjust - Six Color - Magenta Hue | 3 7 9 1 Slider |
| Picture Adjust - Six Color - Magenta Saturation | 3 7 10 |
| Picture Adjust - Six Color - Magenta Saturation | 3 7 10 1 Slider |
| Picture Adjust - Six Color - Yellow Hue | 3 7 11 |
| Picture Adjust - Six Color - Yellow Hue | 3 7 11 1 Slider |

| Menu | Location |
|--|--------------------|
| Picture Adjust - Six Color - Yellow Saturation | 3 7 12 |
| Picture Adjust - Six Color - Yellow Saturation | 3 7 12 1 Slider |
| Picture Adjust - Black Level | 3 8 |
| Picture Adjust - Black Level - High | 3 8 1 |
| Picture Adjust - Black Level - Low | 3 8 2 |
| Picture Adjust - Local Dimming | 3 9 |
| Picture Adjust - Local Dimming - Faster | 3 9 1 |
| Picture Adjust - Local Dimming - Fast | 3 9 2 |
| Picture Adjust - Local Dimming - Normal | 3 9 3 |
| Picture Adjust - Local Dimming - Off | 3 9 4 |
| Picture Adjust - Picture Reset | 3 10 |
| Picture Adjust - Picture Reset - No | 3 10 1 |
| Picture Adjust - Picture Reset - Yes | 3 10 2 |
| Input | 4 |
| Input - Input List | 4 1 |
| Input - Input List - HDMI 1 | 4 1 1 |
| Input - Input List - HDMI 2 | 4 1 2 |
| Input - Input List - DisplayPort | 4 1 3 |
| Input - Input List - USB-C | 4 1 4 |
| Input - Aspect Ratio | 4 2 |
| Input - Aspect Ratio - Full Wide | 4 2 1 |
| Input - Aspect Ratio - Original | 4 2 2 |
| Input - Aspect Ratio - Just Scan | 4 2 3 |
| Input - Aspect Ratio - Cinema 1 | 4 2 4 |
| Input - Aspect Ratio - Cinema 2 | 4 2 5 |
| Input - Auto Input Switch | 4 3 |

| Menu | Location |
|-------------------------------------|----------|
| Input - Auto Input Switch - On | 4 3 1 |
| Input - Auto Input Switch - Off | 4 3 2 |
| Input - PBP/PIP | 4 4 |
| Input - PBP/PIP - Off | 4 4 1 |
| Input - PBP/PIP - Off - HDMI1 | 4 4 1 1 |
| Input - PBP/PIP - Off - HDMI2 | 4 4 1 2 |
| Input - PBP/PIP - Off - DisplayPort | 4 4 1 3 |
| Input - PBP/PIP - PBP(16:9/16:9) | 4 4 2 |
| Input - PBP/PIP - PBP(21:9/11:9) | 4 4 3 |
| Input - PBP/PIP - PBP(11:9/21:9) | 4 4 4 |
| Input - PBP/PIP - PIP | 4 4 5 |
| Input - PIP Size | 4 5 |
| Input - PIP Size - Small | 4 5 1 |
| Input - PIP Size - Large | 4 5 2 |
| Input - PIP Position | 4 6 |
| Input - PIP Position - Bottom Right | 4 6 1 |
| Input - PIP Position - Bottom Left | 4 6 2 |
| Input - PIP Position - Top Left | 4 6 3 |
| Input - PIP Position - Top Right | 4 6 4 |
| Input - Screen Switch | 4 7 |
| Input - Screen Switch - OK | 4 7 1 |
| Input - Sound Switch | 4 8 |
| Input - Sound Switch - OK | 4 8 1 |
| General | 5 |
| General - Language | 5 1 |
| General - Language - English | 5 1 1 |
| General - Language - German | 5 1 2 |

| Menu | Location |
|---|----------|
| General - Language - French | 5 1 3 |
| General - Language - Spanish | 5 1 4 |
| General - Language - Italian | 5 1 5 |
| General - Language - Swedish | 5 1 6 |
| General - Language - Finnish | 5 1 7 |
| General - Language - Portuguese | 5 1 8 |
| General - Language - Portuguese (Brazil) | 5 1 9 |
| General - Language - Polish | 5 1 10 |
| General - Language - Russian | 5 1 11 |
| General - Language - Turkish | 5 1 12 |
| General - Language - Ukrainian | 5 1 13 |
| General - Language - Chinese | 5 1 14 |
| General - Language - Traditional Chinese | 5 1 15 |
| General - Language - Japanese | 5 1 16 |
| General - Language - Korean | 5 1 17 |
| General - User-defined Key 1 | 5 2 |
| General - User-defined Key 1 - Input | 5 2 1 |
| General - User-defined Key 1 - Game Mode | 5 2 2 |
| General - User-defined Key 1 - Crosshair | 5 2 3 |
| General - User-defined Key 1 - Black Stabilizer | 5 2 4 |
| General - User-defined Key 1 - Response Time | 5 2 5 |
| General - User-defined Key 1 - FPS Counter | 5 2 6 |
| General - User-defined Key 1 - PBP/PIP | 5 2 7 |
| General - User-defined Key 2 | 5 3 |

| Menu | Location |
|---|----------|
| General - User-defined Key 2 - Input | 5 3 1 |
| General - User-defined Key 2 - Game Mode | 5 3 2 |
| General - User-defined Key 2 - Crosshair | 5 3 3 |
| General - User-defined Key 2 - Black Stabilizer | 5 3 4 |
| General - User-defined Key 2 - Response Time | 5 3 5 |
| General - User-defined Key 2 - FPS Counter | 5 3 6 |
| General - User-defined Key 2 - PBP/PIP | 5 3 7 |
| General - DTS Headphone:X | 5 4 |
| General - DTS Headphone:X - Game | 5 4 1 |
| General - DTS Headphone:X - Entertainment | 5 4 2 |
| General - DTS Headphone:X - Sports | 5 4 3 |
| General - DTS Headphone:X - Off | 5 4 4 |
| General - SMART ENERGY SAVING | 5 5 |
| General - SMART ENERGY SAVING - High | 5 5 1 |
| General - SMART ENERGY SAVING - Low | 5 5 2 |
| General - SMART ENERGY SAVING - Off | 5 5 3 |
| General - Deep Sleep Mode | 5 6 |
| General - Deep Sleep Mode - On | 5 6 1 |
| General - Deep Sleep Mode - Off | 5 6 2 |
| General - Power LED | 5 7 |
| General - Power LED - On | 5 7 1 |
| General - Power LED - Off | 5 7 2 |

| Menu | Location |
|--|----------|
| General - Automatic Standby | 5 8 |
| General - Automatic Standby - 8H | 5 8 1 |
| General - Automatic Standby - 6H | 5 8 2 |
| General - Automatic Standby - 4H | 5 8 3 |
| General - Automatic Standby - Off | 5 8 4 |
| General - Input Compatibility Version | 5 9 |
| General - Input Compatibility Version - 2.1(PC) / 1.4(DSC) | 5 9 1 |
| General - Input Compatibility Version - 2.1(AV) / 1.4 | 5 9 2 |
| General - Input Compatibility Version - 1.4 / 1.2 | 5 9 3 |
| General - Buzzer | 5 10 |
| General - Buzzer - On | 5 10 1 |
| General - Buzzer - Off | 5 10 2 |
| General - OSD Lock | 5 11 |
| General - OSD Lock - On | 5 11 1 |
| General - OSD Lock - Off | 5 11 2 |
| General - Information | 5 12 |
| General - Reset to Initial Settings | 5 13 |
| General - Reset to Initial Settings - No | 5 13 1 |
| General - Reset to Initial Settings - Yes | 5 13 2 |



Supplier's Declaration of Conformity

| | |
|-------------------|--|
| Trade Name | LG |
| Responsible Party | LG Electronics USA, Inc. |
| Address | 111 Sylvan Avenue, North Building, Englewood Cliffs, NJ 07632 |
| E-mail | lg.environmental@lge.com |

The model and serial number of the product are located on the back and on one side of the product.

Record them below in case you ever need service.

Model _____

Serial No. _____